

PROTOTYPE FORMULA

Toilet Bowl Cleaner with "Green" Actives No. 605

Α	VAN GEL® SX Magnesium Aluminum Silicate Water	Wt.% 2.0 84.5
В	L(+)-lactic acid, 80% (PURAC [®] Sanilac ¹) Sodium Methyl 2-sulfolaurate & Disodium 2-sulfolaurate (ALPHA-STEP [®] MC-48 ²)	10.0 3.5

Procedure:

Step 1 – Add the VAN GEL® SX slowly to the water agitated at high speed. Mix until fully hydrated.

Step 2 – Slowly add the Part B ingredients in order, mixing well after each until uniform. Avoid air entrapment.

RAW MATERIAL SUPPLIERS

¹PURAC America, Lincolnshire, IL ²Stepan Company, Northfield, IL

TRADEMARKS

Registered and pending trademarks appearing printed in bold in these materials are those of Vanderbilt Minerals, LLC. For a complete listing, please visit http://www.vanderbiltminerals.com/ee_content/Documents/Technical/Trademarks_VM_Web.pdf Alpha-Step is a registered trademark of Stepan Company. Purac is a registered trademark of Purac Biochem B.V.

Rev02/07/2014