

Fluoride-Stable Toothpaste No. 613

	Wt. %
A	VEEGUM® D Magnesium Aluminum Silicate 1.50
	Water 41.11
B	Tetrasodium Pyrophosphate 1.00
C	Titanium Dioxide 0.30
D	VANZAN® NF Xanthan Gum 0.80
	Cellulose Gum (Aqualon® CMC 7HF ¹) 0.30
E	Methyl Paraben 0.20
	Propyl Paraben 0.05
	Sorbitol, 70% 10.00
	Glycerin 10.00
	Hydrated Silica (Zeodent® 113 ²) 30.00
	Saccharin 0.20
F	Water 2.80
	Sodium Fluoride 0.24
	Sodium Lauryl Sulfate, 29% 1.50

Procedure: Slowly add the **VEEGUM® D** to the water agitated at maximum available shear. Mix until fully hydrated. Add Part B, Part C, Part D, Part E and Part F in order, mixing after each until uniform.

RAW MATERIAL SUPPLIERS¹Ashland, Inc., Covington, KY²J.M. Huber Corporation, Havre de Grace, MD**TRADEMARKS****VEEGUM** and **VANZAN** are registered trademarks of Vanderbilt Minerals, LLC.

Aqualon is a registered trademark of Hercules, Inc.

Zeodent is a registered trademark of J.M. Huber Corporation

Rev07/01/2013