

AHA Clay Mask No. 486

		Wt. %
A	VEEGUM® <i>Ultra</i> or VEEGUM EZ Magnesium Aluminum Silicate	5.00
	Water	38.25
B	Glycerin	3.00
	Butylene Glycol	3.00
	Cosmetic Kaolin Clay	30.00
	Cosmetic Talc	5.00
	Sodium Lauroyl Sarcosinate, 30%	5.00
C	Glycolic Acid, 70%	7.00
D	Triethanolamine	3.75
	Citric Acid (to pH 4.0 ± 0.2)	q.s.
E	Preservative, Fragrance	q.s.

Procedure: Add the **VEEGUM® *Ultra*** or **VEEGUM EZ** to the water vortex while agitating at maximum available shear. Continue mixing until fully hydrated. Add the remaining ingredients in the order listed, mixing after each addition until smooth.

TRADEMARKS
VEEGUM is a registered trademark of Vanderbilt Minerals, LLC.

Rev01/25/2021