

Liquid Tooth Polish No. 413

		Wt. %
A	VEEGUM® D Magnesium Aluminum Silicate	1.25
	Water	25.15
B	Sorbitol, 70%	12.50
C	Glycerin	12.50
	VANZAN® NF Xanthan Gum	0.70
D	Dicalciumphosphate Dihydrate	45.00
E	Flavor	1.00
	Saccharin	0.20
	Sodium Benzoate	0.20
	Sodium Lauryl Sulfate	1.50

Procedure: Slowly add the **VEEGUM® D** to the water agitated at maximum available shear. Mix until fully hydrated. Add Part B, Part C, Part D and Part E in order, mixing after each until uniform.

TRADEMARKS

VANZAN and **VEEGUM** are registered trademarks of Vanderbilt Minerals, LLC.

Rev07/01/2013