

## Revitalising Face Mask

Formulation-No.: SMI 42/14b

Phase	INCI	Components/Supplier	%	Function
I	AQUA	Water	up to 100	Carrier
	MAGNESIUM ALUMINUM SILICATE	<b>Veegum® ultra (R.T. Vanderbilt)*</b>	5.00	Stabiliser
II	ISOPENTYLDIOL	<b>IPD (Kuraray)*</b>	4.00	Moisturiser
	SORBITOL	Sorbitol	3.00	Moisturiser
	TALCUM	<b>Talkum (C.H. Erbslöh)*</b>	5.00	Cleansing ingredient
	ORYZA SATIVA STARCH	<b>Remytec F-I (Gova)*</b>	30.00	Cleansing ingredient
	ECTOIN	<b>Ectoin® (bitop)*</b>	2.00	Active
	PHENOXYETHANOL, ETHYLHEXYLGLYCERIN	Euxyl® PE 9010 (Schülke & Mayr)	q.s.	Preservative

\*distributed by C.H. Erbslöh

### Procedure:

Add Veegum ultra to the water of phase I while mixing at high speed (3000rpm, 15min). Then add the ingredients of phase II one after the other under stirring. Adjust the final pH to 5.0 with Citric Acid.

**Appearance:** white viscous mask

**pH:** 5.0

**Storage stability:** 3 months/40°C

### DISCLAIMER

The information contained in this document is given in good faith and based on our current knowledge. It is only an indication and is in no way binding, notably as regards infringement of or prejudice to third parties through the use of our products. This information must on no account be used as a substitute for necessary prior tests which alone can ensure that a product is suitable for a given use. Users are responsible for ensuring compliance with local legislation and for obtaining the necessary certifications and authorizations.

