

“Green” Toilet Bowl Cleanser No. 593

		Wt. %
A	VAN GEL® ES Magnesium Aluminum Silicate	1.40
	VANZAN® Xanthan Gum	0.30
	Water	84.80
B	L(+)-lactic acid, 80% (PURAC® Sanilac ¹)	10.00
	Sodium Methyl 2-sulfolaurate & Disodium 2-sulfolaurate (ALPHA-STEP® MC-48 ²)	3.50

Procedure:

Step 1 – Slowly add the **VAN GEL® ES** and **VANZAN®** sequentially or as a dry blend into an established vortex in the water. Mix at maximum available shear until the **VAN GEL ES** is fully hydrated and the **VANZAN** is fully dissolved.

Step 2 – Slowly add the Part B ingredients, mixing well after each until uniform. Avoid air entrapment.

RAW MATERIAL SUPPLIERS

¹PURAC America, Lincolnshire, IL

²Stepan Company, Northfield, IL

TRADEMARKS

Registered and pending trademarks appearing printed in bold in these materials are those of Vanderbilt Minerals, LLC. For a complete listing, please visit

http://www.vanderbiltminerals.com/ee_content/Documents/Technical/Trademarks_VM_Web.pdf

Alpha-Step is a registered trademark of Stepan Company.

Purac is a registered trademark of Purac Biochem B.V.

Rev02/07/2014